



UNIVERSAL Mirror Mod KIT

This kit easily allows the forward-facing amber parking mirror lights to become strobe lights. YES, your lights will still work normally AND work as STROBE when you power unit on.

Fuse each kit at 10 amps, MUST mount module in vehicle in dry location.

- This kit is very simple, it has 2 sets of 2 wires each & the 3 uncovered short wires are your power on (RED), ground (BLACK), and pattern selection (WHITE). Momentary + power to white changes pattern during operation. Fuse the kit at no more than 10amps.
- The 2 longer grey jacketed wires are related to the oem lights positive wires that you want to strobe. You need to find the POSITIVE wires of the lights you wish to flash with a test light....DO NOT GUESS AT THIS, GET A TEST LIGHT OR MULTIMETER. Once you find the positive wire for the lights you want to flash you then CUT that wire leaving you 2 wires. One being the source power and the other being the wire that goes to the actual light itself. Those wires connect to GREY JACKET wires in the kit as follows. Watch the You Tube video for a wire location.
 - KIT BLACK to the oem source 12v + power, (originally powering lights)
 - KIT RED to the oem lights you want to flash, they should be cut free from oem source.

