


# Wicked Warnings Wireless Switch

## Installation and Operation Instructions

**IMPORTANT:** Please read all of the following instructions before installing your new Wireless Switch. **WARNING:** Failure to install or use this product according to manufacturer's recommendations may result in property damage, serious injury, and/or death to those you seek to protect!



### WIRING DIAGRAM



### ABOUT WIRELESS SWITCH

The product is a wireless remote switch with 40A relay. This switch has a wide range of use, is easy to install and easy to use. It lets you turn on or shut off power to household appliances (12V-72V) such as monitor, printer, speakers, and more. It can even be used for industrial equipment or security equipment.

### TECHNICAL INDICATORS

Input voltage: 12V-72V

Output current: 30A

RF working frequency: 433MHz


Range: up to 100m in open field

Receiver sensitivity: -95dbm

Max number of controllers: 16

### HOW TO PAIR A NEW CONTROLLER

- Press the button three times, the LED stays solid green.



- Press the ON button once, the LED will blink green three times then stays solid green.
- Press the OFF button to finish the pairing. Now you have successfully added a new controller.



### HOW TO CLEAR THE MEMORY

Press the button eight times to clear memory then add a new controller again (if you have a problem when you add a new controller).

# WICKED WARNINGS